


# ROD RIG

## Brukerveiledning for Alpacka rafts



1. Stangholder med trykknapp monteres som på bildet og tverrstang settes inn i carbonrøret. Merk høyre og venstre.



2. Legg merke til den lille tappen som viser hvor knappen kan løftes og settes på. I andre stillinger er knappen låst!



3. En eller begge stangholderne monteres på støttestaget.



4. De to carbonstengene settes inn i fremre festehempe. Bredden justeres ved å skyve stangholderen frem eller tilbake på tverrstaget.



5. Tverrstaget festes først inn i den ene festehempen og deretter på den andre siden. Stangen skyves på plass til den står i midten.



6. Lufttrykket i båten holder riggen på plass under dorging. Du kan montere sekk eller bag i mellom stangholderne.



# ROD RIG

## User guide for Alpacka rafts



1. First mount the rod holder with the push button and insert crossbar on the carbon support rod. Please note left and right!



2. Please note the small dot that shows where the button can be lifted and put on. In other positions the button is locked.



3. One or both rod holders may be mounted on the crossbar at your choice.



4. The two carbon rods are inserted in the front grab loops. Adjust the distance by sliding the rod holder on the cross bar.



5. Attach the crossbar into the two grab loops and adjust until centered.



6. The air pressure in the pontoon is keeping the rig in place during trolling. Your travel gear can be mounted between the two rod holders.

